



KAISER KING PIN TOOLING

PLUSKIT	QWIKKIT	BUSH/SEAL DRIVER	QWIKKIT T-HANDLE	REPLACEMENT HEAD	NOGO GAUGE	LIP SEALS	HARDWARE KIT
70.931.12	K931L	ST70-7	ST-100-1	100M1-1	ST81-1	91P1-29	H931L
77.931.18	KG931R	ST70-7	ST-100-1	100M1-1	ST81-1	91P1-29	HG931R
78.931.12	KH931L	ST70-12	ST-100-1	100M1-1	ST81-6	91P1-15	HH931L
79.131.18	K131R	ST70-7	ST-100-1	100M1-1	ST81-1	91P1-29	H131R
70.180.18	K180R	ST70-12	ST-100-1	100M1-1	ST81-6	91P1-15	H180R
	K160A	ST70-31				91P1-48	H160A
70.120.05	K120E	ST70-6	ST-100-1	100M1-1	ST81-4	91P1-25	H120E
70.122.05	K122E	ST70-7	ST-100-1	100M1-1	ST81-1	91P1-29	H122E
70.141.19	K141S	ST70-24	ST-100-1	100M1-1		91P1-34	H141S
70.146.05	K146E	ST70-23	ST-100-3	100M1-2	ST81-5	91P1-36	H146E
70.147.05	K147E	ST70-23	ST-100-3	100M1-2	ST81-5	91P1-36	H147E
70.180.05	K180E	ST70-23	ST-100-3	100M1-2	ST81-5	91P1-36	H180E
	K201S	ST70-24	ST-100-1	100M1-1		91P1-34	H180R
70.533.13	K533M	ST70-6	ST-100-1	100M1-1		91P1-11 91P1-12	H533M
	K536M		ST-100-1	100M1-1		91P10-1 91P11-1	H536M
70.616.13	K616M	ST70-18	ST-100-1	100M1-1		91P1-21 91P1-22	H616M
ECONOKIT 50.121.08		ST70-32				91P1-44	

BUSH & SEAL DRIVER



SPECIALLY DESIGNED TO REMOVE & INSTALL LIP SEALS & BUSHES CORRECTLY & HASSLE FREE

QWIKKIT T-HANDLE



SPECIALLY DESIGNED TO REMOVE & INSTALL QWIKKIT SPIRAL BUSH HASSLE FREE

NOGO GAUGE KIT



TAKE THE GUESS WORK OUT OF MEASURING YOUR AXLE EYE WEAR SIMPLY GO OR NOGO

PLUSKIT®



QWIKKIT®



STEMCO®

Making the Roadways Safer®

AUSTRALIA, NEW ZEALAND, PAPUA NEW GUINEA

Customer Service 02-9793-2599

2/198 Walters Road

Arndell Park NSW 2148 Australia