

# IN-CAB MONITOR - AUDIBLE & VISUAL ALERTS



ALL TYRE PRESSURES & TEMPERATURES ARE OK

LOW PRESSURE WARNING! AUDIBLE & VISUAL SENSOR POSITION,

SENSOR POSITION, LOW PRESURE & AMBER LED'S WILL FLASH EXTREME LOW PRESSURE WARNING! AUDIBLE & VISUAL

SENSOR POSITION, LOW PRESURE & RED LED'S WILL FLASH HIGH TEMPERATURE
WARNING!
AUDIBLE & VISUAL
SENSOR POSITION

SENSOR POSITION, HIGH TEMPERATURE & RED LED'S WILL FLASH HIGH PRESSURE WARNING! AUDIBLE & VISUAL

SENSOR POSITION, HIGH PRESSURE & RED LED'S WILL FLASH

# FEATURE PACKED MOBILE APPLICATION



SCAN & CONNECT TO TRUCKS & TRAILERS WITHIN RANGE



FULLY CONFIGURABLE TRANSCEIVER COMMUNICATION TYPE, ASSET TYPE, NUMBER OF TRAILERS, ETC.



CUSTOMISABLE ALERT
SETTING
LOW PRESSURE,
EXTREME LOW PRESSURE,
HIGH PRESSURE &
HIGH TEMPERATURE



CONNECT TO ASSETS WITHIN RANGE & DISPLAY LATEST TPMS DATA



FULLY UPDATABLE
FIRMWARE FROM
TRANSCEIVER
MODULES & MONITORS



# TYRE PRESSURE MONITORING SYSTEM







## Oz Sensor X BLE Transceiver Module

#### Part Number OZX-TXM

12V/24V Bluetooth Intelligent transceiver mounted to each truck or trailer transmits data directly to an in-cab monitor or smartphone. Transceiver box can be integrated with existing telematics systems including CAN, RS232, RS485 & BLE 2.4GHZ.

# Oz Sensor X In-Cab BLE Monitor/Display

#### Part Number OZX-TMON

12V/24V Bluetooth In-Cab Monitor/Display displays tyre pressure & temperatures with various audible & visual alert levels for high temperature, high & low tyre pressure.



# Oz Sensor X Flow Through Sensor

#### Part Number OZX-FTXX

Bluetooth flow through tyre valve sensor, gives you the ability to increase or decrease tyre pressure without removing the sensor. "XX" for Axle/Wheel Location.



## Oz Sensor X Cap Sensor

#### Part Number OZX-CXX

Bluetooth tyre valve sensor, "XX" for Axle/Wheel location.



# Oz Sensor X Flex Rubber Extension

#### Part Number OZX-FE235-FTXX

Flexible rubber extension 235mm long flow through sensor "XX" for Axle/Wheel location



# Oz Sensor X Flex Hose Metal Clamp

Part Number OZX-MC15S

Flexy hose metal clamp 15mm suit steel rims.



# Oz Sensor X Flex Hose Metal Clamp

#### Part Number OZX-MC25A

Flexy hose metal clamp 25mm suit aluminum rims.



# Oz Sensor X Plastic Valve Extension

#### Part Number OZX-PE140

White plastic valve extension 140mm long.

# Oz Sensor X Complete Tool Kit

#### Part Number OZX-TK

ZYKUX has created a tool & service kit to ensure hassle free installation & maintenance.



# KIT CONTENTS

- 1. TORQUE DRIVER TOOL 3NM
- 2. FLOW THROUGH SENSOR FITTING SOCKET
- 3. 10MM SPANNER (FOR EXTENSION CLAMP)
- 4. ADAPTER FOR TORQUE DRIVER TOOL
- 5. O-RING FITTING TOOL FOR FLOW THROUGH SENSOR
- 6. FLEXY/EXTENSION SENSOR FITTING TOOL
- 7. 300MM EXTENSION FOR TORQUE DRIVER TOOL
- 8. 0-RINGS FOR FLOW THROUGH SENSOR
- 9. O-RINGS FOR FLEXY EXTENSION SENSOR



AUSTRALIA, NEW ZEALAND, PAPUA NEW GUINEA **Customer Service 02-9793-2599** 

> 2/198 Walters Road Arndell Park NSW 2148 Australia