

AXLE	DESCRIPTION	CONTENTS	PART NUMBER
TRAILER	COMMON TN TRAILER TAPERED BEARINGS (INCLUDES HUB INSTALLED WHEEL SEAL)	SET414STM & SET413STM VOYAGER SEAL 373-0143 AUTO-TORQ AXLE NUT	KIT-TNATV
TRAILER	COMMON TN TRAILER TAPERED BEARINGS (INCLUDES AXLE INSTALLED WHEEL SEAL)	SET414STM & SET413STM GUARDIAN HP SEAL 307-0743 AUTO-TORQ AXLE NUT	KIT-TNATG
TRAILER	COMMON TP TRAILER PARALLEL BEARINGS (INCLUDES HUB INSTALLED WHEEL SEAL)	2x SET415STM VOYAGER SEAL 373-0123 AUTO-TORQ AXLE NUT	KIT-TPATV
TRAILER	COMMON TP TRAILER PARALLEL BEARINGS (INCLUDES AXLE INSTALLED WHEEL SEAL)	2x SET415STM GUARDIAN HP SEAL 307-0723 AUTO-TORQ AXLE NUT	KIT-TPATG

AUTO-TORQ sets the wheel end into optimum bearing adjustment for maximum wheel end life.

MAXIMIZES BEARING LIFE

By applying optimum clamp load on the bearings every-time, it reduces bearing wear which results in longer bearing service life.


No need for spacers, half-stand bearings and precision hubs necessary for "PreSet" systems. Combine with STEMCO industry-leading seals, bearings & ESP hub caps for extended service life.

EASY OF INSTALLATION

Auto-Torq technology takes the guesswork out of axle fastener installation by eliminating complex processes and specialty tools.

This allows for quicker installation time with improved peace of mind that the installation is performed correctly.

Bearing Adjustment vs. Bearing Life





SAFE. SECURE. SIMPLE.





